

How to connect the fiber optic splice tray and the optical splitter





How to connect the fiber optic splice tray and the optical splitter

8 Port Fiber Distribution Box with Cable Gland, 10 Cores

The 8 Port Fiber Distribution Box supports 2 cable entries (4-8 mm) and can house one 1x8 blockless splitter and 8 sc adapter for 8 cores termination and 10

8 Port Fiber Access Terminal (FAT) with Mid-span Entry

The 8 port termination box supports 2 entry cables with Dia

Contact Us

For datasheets, pricing, or custom optical networking solutions, please visit:
<https://entrenamientointeligente.es>